



TEL150 / 1/4" Corrugated Cable Connector Installation Guide

N Male

Shrink Sleeve	Pin	Insulator	Connector Body
	<p>Trim the cable to the dimensions shown on the image on the left.</p> <p>Side Crimp the Shrink Sleeve.</p> <p>Braid the Wires & Inner Conductor.</p>		
	<p>Insert the Cable into the Insulation and Contact Pin until it is fully seated.</p> <p>Once in position Solder the Pin to the Conductor.</p>		
	<p>Insert the assembly into the connector body.</p> <p>Then solder the Heat Shrink sleeve to the Rear of the Connector and down onto the Cable Jacket using Glue Walled Heat Shrink.</p>		