

## Mobile Broadband Data Card Connector Sheet

<b>Manufacturer</b>	<b>Model</b>	<b>Connector</b>	<b>Device Type</b>
<b>HUAWEI</b>			
Huawei	E160	CRC9	USB Modem
Huawei	E160E	CRC9	USB Modem
Huawei	E160G	CRC9	USB Modem
Huawei	E156G	CRC9	USB Modem
Huawei	E159	CRC9	USB Modem
Huawei	E153	CRC9	USB Modem
Huawei	E122	CRC9	USB Modem
Huawei	E1553	CRC9	USB Modem
Huawei	E161	CRC9	USB Modem
Huawei	E1612	CRC9	USB Modem
Huawei	E166	CRC9	USB Modem
Huawei	E169	CRC9	USB Modem
Huawei	E173	CRC9	USB Modem
Huawei	E176	CRC9	USB Modem
Huawei	E176G	CRC9	USB Modem
Huawei	E1762	CRC9	USB Modem
Huawei	E182	CRC9	USB Modem
Huawei	E182E	CRC9	USB Modem
Huawei	E1820	CRC9	USB Modem
Huawei	E1823	CRC9	USB Modem
Huawei	E196G	CRC9	USB Modem
Huawei	E367	CRC9	USB Modem
Huawei	E353	CRC9	USB Modem
Huawei	E398	TS-9	USB Modem
Huawei	K4505	CRC9	USB Modem
Huawei	K4511	CRC9	USB Modem
Huawei	K3771	CRC9	USB Modem
Huawei	UMG181	CRC9	USB Modem
Huawei	UMG1691	CRC9	USB Modem
Huawei	E600	CRC9	PCMCIA Card
Huawei	E612	CRC9	PCMCIA Card
Huawei	E618	CRC9	PCMCIA Card
Huawei	E620	CRC9	PCMCIA Card
Huawei	E621	CRC9	PCMCIA Card
Huawei	E630	CRC9	PCMCIA Card
Huawei	E660	CRC9	PCMCIA Card
Huawei	E660A	CRC9	PCMCIA Card
Huawei	E881E	CRC9	Express Card
Huawei	E800	SSMB	Express Card

Huawei	E870	SSMB	Express Card
Huawei	E880	SSMB	Express Card
Huawei	B932	SMA	Router
Huawei	B933	SMA	Router
Huawei	B970	SMA	Router
Huawei	E960	SMA	Router
Huawei	E968	SMA	Router
Huawei	E583C	CRC9	Router
Huawei	B220	SMA	Router

**SIERRA WIRELESS**

Sierra Wireless	AC 880U	SSMB	USB Modem
Sierra Wireless	AC881	SSMB	USB Modem
Sierra Wireless	AC881U	SSMB	USB Modem
Sierra Wireless	APEX880	SSMB	USB Modem
Sierra Wireless	Compass 885	TS-9	USB Modem
Sierra Wireless	Compass 888	TS-9	USB Modem
Sierra Wireless	Compass 889	TS-9	USB Modem
Sierra Wireless	USB597	TS-9	USB Modem
Sierra Wireless	USB598	TS-9	USB Modem
Sierra Wireless	AC250U	TS-9	USB Modem
Sierra Wireless	AirCard 301	TS-9	USB Modem
Sierra Wireless	AirCard 302	TS-9	USB Modem
Sierra Wireless	AirCard 305	TS-9	USB Modem
Sierra Wireless	AirCard 306	TS-9	USB Modem
Sierra Wireless	AirCard 307	TS-9	USB Modem
Sierra Wireless	AirCard 308	TS-9	USB Modem
Sierra Wireless	AirCard 309	TS-9	USB Modem
Sierra Wireless	AirCard 310	TS-9	USB Modem
Sierra Wireless	AirCard 312	TS-9	USB Modem
Sierra Wireless	PCMCIA AC555D	SSMB	PCMCIA Card
Sierra Wireless	PCMCIA AC503	TS-9	PCMCIA Card
Sierra Wireless	PCMCIA AC504	TS-9	PCMCIA Card
Sierra Wireless	PCMCIA AC580	SSMB	PCMCIA Card
Sierra Wireless	PCMCIA AC775	SSMB	PCMCIA Card
Sierra Wireless	PCMCIA AC850	SSMB	PCMCIA Card
Sierra Wireless	PCMCIA AC860	SSMB	PCMCIA Card
Sierra Wireless	PCMCIA AC875	SSMB	PCMCIA Card
Sierra Wireless	PCMCIA AC880	SSMB	PCMCIA Card
Sierra Wireless	AC402	TS-9	Express Card
Sierra Wireless	AC501	TS-9	Express Card
Sierra Wireless	AC502	TS-9	Express Card
Sierra Wireless	AC503	TS-9	Express Card
Sierra Wireless	AC597E	SSMB	Express Card
Sierra Wireless	AC880E	SSMB	Express Card
Sierra Wireless	AC881E	SSMB	Express Card

**NOVATEL WIRELESS**

Novatel Wireless	MCD3000	MS-147	USB Modem
Novatel Wireless	U720	MS-147	USB Modem
Novatel Wireless	U727	TS-9	USB Modem
Novatel Wireless	U760	TS-9	USB Modem
Novatel Wireless	MC727	TS-9	USB Modem
Novatel Wireless	MC760	TS-9	USB Modem
Novatel Wireless	MC930D	Universal	USB Modem
Novatel Wireless	MC950D	Universal	USB Modem
Novatel Wireless	C770	TS-9	USB Modem
Novatel Wireless	C777	TS-9	USB Modem
Novatel Wireless	3G QUAD	MC-Card	PCMCIA Card
Novatel Wireless	Express 7.2	MC-Card	PCMCIA Card
Novatel Wireless	7.2 HSDPA	MC-Card	PCMCIA Card
Novatel Wireless	EDGE	MC-Card	PCMCIA Card
Novatel Wireless	GT EDGE	MC-Card	PCMCIA Card
Novatel Wireless	GlobeTrotter FUSION	MC-Card	PCMCIA Card
Novatel Wireless	GlobeTrotter GT MAX	MC-Card	PCMCIA Card
Novatel Wireless	HSDPA	MC-Card	PCMCIA Card
Novatel Wireless	MAX HSDPA	MC-Card	PCMCIA Card
Novatel Wireless	GlobeSurfer	MC-Card	PCMCIA Card
Novatel Wireless	Express HSUPA	MC-Card	Express Card
Novatel Wireless	Express HSDPA	MC-Card	Express Card
Novatel Wireless	GlobeSurfer II	MC-Card	Router
Novatel Wireless	GlobeSurfer III	MC-Card	Router

**ZTE**

ZTE	MF633	TS-9	USB Modem
ZTE	MF633BP+	TS-9	USB Modem
ZTE	MF626i	TS-9	USB Modem
ZTE	MF645	TS-9	USB Modem
ZTE	MF668	TS-9	USB Modem
ZTE	MF668+	TS-9	USB Modem
ZTE	MF60	TS-9	USB Modem
ZTE	MF622	MS-147	USB Modem
ZTE	MF636+	M852	USB Modem

**SONY ERICSSON**

Sony Ericsson	EC400	SSMB	Express Card
Sony Ericsson	EC400G	SSMB	Express Card
Sony Ericsson	PC300	SSMB	PCMCIA Card
Sony Ericsson	W20	SMA	Router
Sony Ericsson	W21	SMA	Router
Sony Ericsson	W25	SMA	Router
Sony Ericsson	W30	MCX	Router
Sony Ericsson	W35	MCX	Router